

The seat is a simple lightweight attachment for the GoKart trolley. Before you can use it, the seat bracket has to be attached to the trolley behind one of the wheels. It can go on either side. Once fitted, the bracket stays on the trolley, and the post and seat assembly can just be clipped on or off when needed. You should always remove the seat after use as dried mud can stop it working properly.

1. Unfold your GoKart and fit the battery.
2. Remove the wheel on the side that the seat is to be fitted (picture 1).
3. Use the loose wheel as a jack (picture 2).
4. Drop the spring into the upper half of the bracket (picture 3).
5. Fit the bracket the right way round (pictures 4 and 5).
6. Fit both halves of the bracket to the trolley using all four screws (picture 6).
7. Re-fit the wheel (picture 7).
8. Clip the seat post into the seat itself (picture 8).
9. Slide the seat post into the bracket (picture 9).
10. Have a seat!

